

## HK-035: Hardware Kit for Cable Strain Relief Kit

The HK-035 encompasses all the necessary parts to provide strain relief for any iCCU-S2 Cable (e.g. CABLE-A/B/C/D), or Adapter Cable (e.g. 50PINADP) that is plugged into the front of an iCCU-S2.

A cable tie anchor mounts to one of the threaded inserts on the side wall of the iCCU-S2 (using a supplied screw). The cables get zip tied to this anchor using zip tie supplied, thus relieving any strain on the cables.



### Installation Instructions:

Determine which of the 4 threaded inserts on the left side of an iCCU-S2 will best accommodate the routing of cables to their final destination. Polara recommends using either the upper, or lower insert closest to the front of the iCCU.

Mount anchor to the threaded insert using M3 screw supplied (M3-0.5X6). The screw will bottom out at 5-7 turns and the anchor will still be loose/spin. If you do not want it to spin, use two flat washers (not supplied) along with the M3 screw. Installing both on the screw will cause some interference for the tie wrap, but it will still pass through. Placing one washer on the screw, and one under the anchor will reduce this interference.

**Note:** The swaging of the insert into the aluminum panel compresses the threads slightly such that the first 1-2 turns of the screw may be a little tight.

Route the zip tie through the anchor, position cable in the anchor, and tighten zip tie around cables.